

GAZELLE®

GC1010 GC1020 GC1040 GC1050 Battery Pack User Manual



OPERATION INSTRUCTIONS

Rechargeable Li-ion Battery Pack



Illustrations, figures and photos may vary slightly due to program of continuous product improvements, please in kind prevail.

Attention

1. The battery pack is stored in an ambient temperature range of 0-45°C . The battery pack capacity will be affected if the ambient temperature is too high or too low when the battery pack is stored.
2. In order to prolong the service life, do not store the completely exhausted battery pack directly. Please charge the battery pack in time after use.
3. For long-term storage (more than 3 months), it is recommended to remove the fully charged battery pack from the charger, store it in a cool and dry place, and recharge the battery pack every 6 months.
4. The allowable charging ambient temperature range of the battery pack is 5-40 °C , and the ambient humidity is $\leq 90\%$ RH.
5. If the life of the battery pack is significantly shortened after each charge, please replace the battery pack with a new one or go to the maintenance site to check.
6. Do not dispose of discarded battery packs in general household trash, fire or water.
7. To protect natural resources, please recycle or

dispose of batteries properly. The battery contains lithium. Consult your local authority for information on recycling and/or disposal. Remove the battery after it has run out of power and wrap the pole port with strong tape to avoid short circuit and leakage. Any attempt to open or remove any component is strictly prohibited.

Battery safety warning

- a) Do not dismantle, open or shred secondary cells or batteries.
- b) Keep batteries out of the reach of children
Battery usage by children should be supervised.
Especially keep small batteries out of reach of small children.
- c) Do not expose cells or batteries to heat or fire. Avoid storage in direct sunlight.
- d) Do not short-circuit a cell or a battery. Do not store cells or batteries haphazardly in a box or drawer where they may short-circuit each other or be short-circuited by other metal objects.
- e) Do not subject cells or batteries to mechanical shock.
- f) In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
- g) Do not use any charger other than that specifically provided for use with the equipment.
- h) Do not use any cell or battery which is not designed for use with the equipment.
- i) Do not mix cells of different manufacture, capacity, size or type within a device.
- j) Always purchase the battery recommended by the

device manufacturer for the equipment.

- k) **Keep cells and batteries clean and dry.**
- l) **Wipe the cell or battery terminals with a clean dry cloth if they become dirty.**
- m) **Secondary cells and batteries need to be charged before use. Always use the correct charger and refer to the manufacturer's instructions or equipment manual for proper charging instructions.**
- n) **Do not leave a battery on prolonged charge when not in use.**
- o) **After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance.**
- p) **Retain the original product literature for future reference.**
- q) **Use the cell or battery only in the application for which it was intended.**
- r) **When possible, remove the battery from the equipment when not in use.**
- s) **Keep the cell or battery away from microwaves and high pressure.**
- t) **Dispose of properly.**

INNOVATION
PERFORMANCE
SAFETY
CONFIDENCE
GAZELLE

GAZELLE

sales@gazelleindustrial.com | www.gazelleindustrial.com